

Parts & Fittings Supplied

Ref	Description	Illustration	Qty
A	Back Frame		1
B	Front Frame		1
C	Side Panel		2
D	Lid		1
E	Side Panel Bar (a)		2
F	Side Panel Bar (b)		2
G	Large Screws		4
H	Small Screws		4
I	Vent Clips		2
J	Ground Pegs		4

Before You Start

Please check that all components are present and read through these instructions carefully.

Assembly

1. Join back panels (A) with front panels (B) using the short side bars (E) and large screws (G). Note that they do not screw in entirely: they are used for the ground anchors.
2. Slide one side panel C into place and add long side bar F. Secure top corners with small screws (H).
3. Repeat for the other side.
4. Slide lid (D) along the groove in panel (A) until into position. (**See Fig 1**). The Cold Frame is now complete.
5. Use ground pegs J to secure the Cold Frame to soft ground. (**See Fig 2**).
6. Ventilate the Cold Frame using the 2-stage vent clips (I) on the top edge of front panel (B) (**see Fig 3**) or by sliding lid (D) along as required.

