

# Large wooden cold frame

## Before You Start

Please check that all components are present and read through these instructions carefully.

## Assembly

1. Check all screws are tight in the ready-made frame sections but avoid over-tightening.
2. Do not yet remove the protective covers on the polycarbonate glazing: note the cover is on the outside of the panels.
3. Assemble the frame as shown (See Fig 1) using screws (H) and the pre-drilled holes.
4. Fix the base plates (G) on the underside of two corners as required (See Fig 2).
5. Add the lid section and secure to the frame using screws (H1) and the pre-drilled holes.
6. To assemble the lid support arms:  
Insert the bolts (F) from the outside, through the slots in the support arms and into the pre-drilled holes in the side panels. Screw in part way to secure. (See Fig 3).  
The wing bolt can be tightened when the lid is in the required position.
7. To complete the assembly, peel off the protective sheet from the polycarbonate panels and site the cold frame in good light but out of prolonged fierce sunlight. Use the corner base plates to peg or bolt down the cold frame if extra security is required.

## Care & maintenance

- Extra coatings of wood preservative will prolong the life of the product but be sure to use one that is harmless to plants.
- Avoid constant contact with wet soil by mounting the frame on bricks, slabs or wooden battens.

## Helpline Number

If you have any problems or queries with this product please call our helpline on +44 (0)1406 372227 between the hours of 9am to 5.30pm Monday to Friday.

## Parts & Fittings Supplied

Ref	Description	Illustration	Qty
A	Glazed Front Panels		2
B	Glazed End Panels (hinged)		2
C	Glazed Double Lid (hinged)		1
E	Lid Supports (in place)		4
F	35mm Wing Bolt 2 and Washer		4
G	Base Plates		2
H	Frame Screws		8
H1	Long Ridge Screws		4
J	Base Plate Screws		8

