








GARDMAN

HANGING FEEDING STATION

Contents	AXI	BXI	CXI	DXI
				



Instructions

Site out of reach of predators.

care

We recommend that you clean your feeding station in a mild disinfectant solution once every two months or more often in warm weather. Dis-assemble feeding station and remove as much old food and debris as possible.

Wash in the solution and thoroughly rinse with clean water.

Periodically reposition your feeder to a different area within the garden to avoid an accumulation of unhygienic deposits.

GARDMAN LIMITED
Moulton, Spalding,
Lincolnshire, PE12 6QD, UK.

Helpline
01406 372227