

**GARDMAN**


# Jebao®

捷寶

SUBMERSIBLE PUMP

## OWNER'S MANUAL

Jebao pumps are carefully tested and certified to ensure both safety and operating performance. Failure to follow the instructions and warnings in this manual may result in pump damage and/or serious injury. Be sure to read, thoroughly understand, and save this manual for future reference.



**GARDMAN**

Gardman Ltd, High Street, Moulton,  
Spalding Lincolnshire, PE12 6QD, UK  
Telephone: +44 (0) 1406 372222  
Consumer Helpline: +44(0)1406 372227  
[www.gardman.co.uk](http://www.gardman.co.uk)



## INSTRUCTIONS

1. Only the pump and the electrical cord directly connecting the two are to come in contact with water. Under no circumstances should the other parts come into contact with water.
2. Do not plug-in or otherwise use this product if any part of it appears to be damaged or operates abnormally. Have the product examined and repaired if necessary by a qualified electrician.
3. Make a "drip loop" on the electrical cord connecting the pump to the plug by letting a portion of the cord hang lower than either the pump or the plug.
4. Do not let the pump run when not submerged in water. Doing so may damage the pump. Always submerge the pump first, and then plug in the unit. At the beginning, it probably can't pump water, because there is air in the pump and the tube. Don't worry about it. Please pull out and insert electrical outlet several times, it will work very well at once.
5. Take care to ensure excess power cords are stowed so as to avoid tripping.
6. Operate the unit only under constant adult supervision and monitoring.  
Keep the unit unplugged when not under direct observation.
7. Use this product indoors only.

## MAINTENANCE

1. Use this pump with distilled water only. Mineral build up from tap water, or water from other sources, can ruin the pump.
2. No maintenance is necessary when this product is used in the manner described in this manual.
3. If debris is caught in the intake vents of the pump, disconnect the pump from any power sources and rinse the pump under clean running water.